


Arlington Basin & Pedestal Installation Instructions

Code: AR6047P

Notes:

- This basin does not come with fixing bolts, tapware, or waste outlet
- This basin can not be wall mounted on its own, it requires a pedestal to sit on, or bench to sit in

How to install basin on pedestal:

<p>Step 1: Install tapware and waste (not included) into basin, without connecting anything to water supply or waste</p>	<p>Step 2: Sit basin on pedestal in selected position on the wall</p>
<p>Step 3: Mark fixing holes on left and right side of basin</p> 	<p>Step 4: Pull basin away from wall and insert best wall fixing for type of wall For example:</p> <ul style="list-style-type: none"> • Concrete or brick walls – insert plugs • Plasterboard wall with timber behind it – drill pilot hole ready for screw • Plasterboard wall with no timber behind it – install expanding hollow wall anchor
<p>Step 5: Apply wet area bathroom silicone around base of pedestal (to secure pedestal to the floor), top of pedestal (to secure basin to pedestal), and on wall behind basin, then insert fixing screw with plastic washer on left and right side of basin to secure basin to the wall. Finally apply silicone around outside of basin.</p>	<p>Step 6: Install trap onto the waste outlet and into the waste pipe in the wall, and connect tapware to water supply.</p> <p>Done!</p>