

# INSTALLATION INSTRUCTIONS



## Top Assemble Parts list

Rubber seal to suit 20mm copper tube



## Bottom Assemble Parts List

Grey 50mm rubber seal

50 mm Mi connector ( not supplied )



## INSTRUCTION

1. Determine desired finish height of Urinal.  
Recommended 530-600mm to the rim.
2. Fix brackets to the wall ( use appropriate fixings for the job at hand.
3. Attach top and bottom seals to the urinal and the 50 mm MI adaptor. Lube will be required on the PVC fitting & rubber key seal.
4. Install urinal to the wall, and connect inlet & outlet pipes.
5. Flush through the urinal on completion & test for leaks.
6. Clean the wall and urinal then apply Sanitary grade silicone.